

T7503

Paging Transmitter

08.06.09

QUICK REFERENCE SHEET

Adding to Waitlist

- 1) Press Wait button
- 2) At the Add Walk-In Wizard:
 - a. Enter the Guest's Party Size, press Enter
 - b. Enter the Quote Wait Time, press Enter
 - c. Enter the Name of the party
 - d. Enter the Guest Pager if handing out an on-premise pager or Mobile Phone to use the guest's cell phone as a pager (Only with Click Ahead Seating), press Enter
 - e. If required, select preferences (e.g. Smoking, Table/Booth/Patio, Occasion, Special Need)

Paging

To page a guest that their table is ready:

- 1) Select a party from the waitlist by using the up/down arrow keys, press Enter
- 2) Select an open table using the arrow keys and confirm by pressing the Enter key.
- 3) Guest will now be paged and their table number will be displayed next to the party's name.

To page manager pager:

- 1) To page a manager, use the M1, M2, or M3 keys.
- 2) a. For star pagers, select Vibe 1, 2, 3 or Vibe/Beep Twice option to send a page
b. For alphanumeric pagers, select a preset message or type a custom message and press the send button on the touch screen.

To page a guest pager:

- 1) Press the Page button on the transmitter 4-button keypad.
- 2) Type in the pager number and press Enter to send the page.

To page a staff:

- 1) Press the Staff button on the transmitter main keypad.
- 2) Type in the pager number, press Enter
- 3) a. For Star Staff pagers, select the type of vibration alert to send and press Enter.
b. For Alpha pagers, enter a preset message from 000 – 099 and press Enter

Edit Table Status

- 1) Press Tbl Stat on transmitter 4-button keypad.
- 2) Using the arrow key on the keypad, highlight a table number and press Edit on the transmitter main keypad.
- 3) When dialogue box appears, press a corresponding button on the transmitter main keypad to select an option for tables.

Note: Open and Close all tables can be done from any table number.

